

2.9 CoreClad Vertical Sheet joint Cavity System

Ensure fixings are clear of weather-grooves

Fix each sheet of CoreClad independently (Do not fix through top lap)

IBuilt™ 12mm H3.2 CoreClad cladding

Use temporary 9mm spacer while fixing sheets

20mm Cavity Battens

Breather type building underlay to E2/AS1 continuous behind sheet joint

